



Installation Instructions for Shielding

1.As shown in the drawing, drill 4 M4 screw holes on the heat sink corresponding to the holes on the shielding (the holes are the same for 60-200W)

2.Fix the shielding to the heat sink as shown in the drawing.