



SB-PSC3 Drywall Hanging Kit for Edged lit Flat Panel.







10' cable long each, total 4 pcs cables for 2x2 flat panel, 6 pcs cables for 1x4 and 2x4 flat panel



1. A.Fix the anchor into target place on the ceiling. B.Fix the installation mount on the ceiling with plastic anchor.



2. Hang the panel to ceiling suspending installation kits



3. Adjust the length of steel wire. Connect the power supply