### **WARNING**

- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards read all warnings and instructions included with and on the fixture box and all fixture labels.
- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- Commercial installation, service and maintenance of luminaires should be performed by a qualified licensed electrician.
- For the installation: If you are unsure about the installation or maintenance of the luminaires, consult a qualified licensed electrician and check your local electrical code.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.

### **A** WARNING

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- All wiring connections should be capped with UL approved wire connectors.

### **A** CAUTION

- Avoid direct eye exposure to the light source while it is on.
- Account for small parts and destroy packing material, as these may be hazardous to children.
- Risk of burn. Disconnect power and allow fixture to cool before changing bulb or handing fixture.


**NOTICE**: Green ground screw provided in proper location. Do not relocate.

**NOTICE**: Minimum 90°C supply conductors.

**NOTICE**: Specifications and dimensions subject to change without notice.


NOTICE: Suitable for Dry or Damp location

### **General Wiring Diagram**




### Surface mount to ceiling


Notice: Always turn off the power supply from main circuit breaker first!



- Step 2: Place the luminaire on the junction box as a template, then mark the positions of 4 mounting holes in the ceiling.
- Step 3: Put the luminaire aside and drill 4 mounting holes. Insert anchor into each hole.
- Step 4: Make wiring in junction box(by others) refer to local Regulations and Codes. Attach the cover plate to the Junction box with screws(by others).
- Step 5: Screw in the screws one by one to hang the fixture firmly.
- Step 6: Reattach the lens.
  - a. Insert whole lens slot onto one side-edge of housing.
  - b. Carefully squeeze one end of the lens to engage opposite side-edge of the housing.




## End-cap with Knockout optional



Enhance the flexibility of wiring, daisy chain and installation.

## Field-Adjustable Wattage & CCT




The end users may adjust the color temperature and lumen output respectively by the two DIP switches. CCT switch is accommodated with 5 CCT options (3000K, 3500K, 4000K, 5000K, 6500K), and Power switch is accommodated with 4 Power options. The switches can perform the desired color temperature and lumen output combination.

Select a wattage and color temperature by sliding switch left or right respectively to the desired value.

#### **Additional Accessories**

DC12V Sensor



- Step 1, Remove the sensor hole cover-plate before or after installing the fixture in the ceiling.(Fig. 1)
- Step 2, Remove the flat cable that were secured on the back of the plate.
- Step 3, Insert the terminals into the approved sensor. (Fig. 2)
- Step 4, Install the approved sensor and make sure it is securely fit. (Fig. 3)

### **General Wiring Diagram**

